

## **Komatsu Gd530a-2ey, Gd530aw-2ey, Gd650a-2ey, Gd650aw-2ey, Gd670a-2ey Service Repair**

This is a COMPLETE Operation & Maintenance Manual for the KOMATSU GD530A-2EY, GD530AW-2EY, GD650A-2EY, GD650AW-2EY, GD670A-2EY, GD670AW-2EY MOTOR GRADER WITH EMISSIONIZED [ENGINE](#).



MACHINE MODEL SERIAL NUMBERS GD530A-2EY, AW-2EY - 210098 and UP GD650A-2EY, AW-2EY -



210098 and UP GD670A-2EY, AW-2EY - 210098 and UP

## **Komatsu Gd530a-2ey, Gd530aw-2ey, Gd650a-2ey, Gd650aw-2ey, Gd670a-2ey Service Repair**

### TABLE OF CONTENTS:

===== INTRODUCTION 1. GENERAL 2. PIN LOCATIONS 3. SERIAL NUMBERS (S/N) 4. MACHINE SHIPPING 5. LIFTING THE MACHINE FOR TRANSPORT 6. MOVING A DISABLED MACHINE 7. MACHINE STORAGE 8. ROLLOVER PROTECTIVE STRUCTURE (ROPS) 9. TABLE OF CONTENTS SAFETY 10. GENERAL PRECAUTIONS 11. SOUND AND VIBRATION 12. OPERATIONAL SAFETY OPERATION 13. UNIVERSAL SYMBOLS 14. PREPARATION FOR USE 15. OPERATIONAL CONTROLS AND INSTRUMENTATION 16. PRECAUTIONS 17. PREPARATION FOR ROADING OR JOB SITE OPERATION 18. EMERGENCY STOPPING 19. PARKING THE GRADER 20. TROUBLESHOOTING GUIDE 21. OPERATION UNDER UNUSUAL CONDITIONS 22. APPLICATION MAINTENANCE 23. MAINTENANCE 24. SERVICE PROCEDURE 25. OIL CHANGE RECOMMENDATIONS 26. OIL, FLUIDS AND GREASE 27. WEAR LIMITS 28. FUEL, COOLANT AND LUBRICANTS ACCORDING TO AMBIENT TEMPERATURE 29. VENTING AND PRIMING ENGINE 30. ENGINE CRANKCASE VENTILATION 31. ELECTRICAL SYSTEM 32. SPEEDOMETER CALIBRATION 33. TIRES 34. TURBOCHARGER SPECIFICATIONS 39. GENERAL DESCRIPTION 40. GENERAL SPECIFICATIONS 41. TORQUE VALUES FOR STANDARD ENGLISH FASTENERS 42. TORQUE VALUES FOR STANDARD METRIC FASTENERS 43. TORQUE VALUES FOR HOSE CLAMPS 44. TORQUE VALUES FOR SPLIT FLANGE CONNECTIONS 45. TORQUE VALUES FOR HYDRAULIC TUBES AND FITTINGS 46. SPECIFIC BOLT TORQUES 47. DECALS OPTIONS, ATTACHMENTS 49. HEATING AND AIR CONDITIONING 50. [ALL WHEEL DRIVE](#) 51. BATTERY CHARGING RECEPTICLE 52. COLD-WEATHER

STARTING AID 53. [FIRE EXTINGUISHER](#) 54. [HYDRAULIC ACCUMULATOR](#) (DRAWBAR AND CIRCLE OPTION) 55. HYDRAULIC LOCK/UNLOCK DIFFERENTIAL 56. FRONT BLADE ATTACHMENT 57. FRONT-MOUNTED SCARIFIER 58. MASTER SWITCH 59. REAR-MOUNTED RIPPER 60. SPARE TIRE 61. WHEEL CHOCKS 62. WORK LIGHT SOCKET 63. ELECTRIC FLOAT 64. AM/FM/WB STEREO RADIO

=====

Model Specification: KOMATSU GD530A-2EY, GD530AW-2EY, GD650A-2EY, GD650AW-2EY, GD670A-2EY, GD670AW-2EY MOTOR GRADER WITH EMISSIONIZED ENGINE

*Komatsu Gd530a-2ey, Gd530aw-2ey, Gd650a-2ey, Gd650aw-2ey, Gd670a-2ey Service Repair*